


L14 Lite Atombook


USER MANUAL

Contents

Monitor Introduction 3
Package List 4
FAQ 5
Monitor Specifications 6


Monitor Introduction





The way to turn on the laptop is to press the button, please press the power button to turn on it. Please click "power off in the Os to turn off the laptop. Pressing the power button for several seconds by force to turn off the laptop can be used in special circumstances. What customers need to pay attention to is that frequent power-off by force may cause system files missing or crash of the laptop.

Package List




Atombook


Bluetooth keyboard



Keyboard charging cable



Stylus pencil



Adapter



User Manual

FAQ

Questions	Answers
Laptop can't boot	 Check if the battery is fully charged. Check the power adapter before restarting the machine again. If it is still unable to boot after charging, please contact us.
WIFI can't work	 Please confirm whether there is a WIFI hotspot. Make sure that the is connected to the WIFI (enter the settings to check). Please confirm the WIFI signal strength and link permission.
Active Stylus Support	The laptop supports MPP protocol active stylus, but due to the different manufacturers of active stylus, the drawing effect will be different, and the actual effect shall prevail.

Monitor Specifications

Model	L14 Lite
System	Windows
CPU Brand	Intel N100
RAM/ROM	12GB/256GB
Screen size	14.1inch
Resolution	1920*1200
Color Gamut	72%NTSC
Brightness	300CD/M ²
Network Connection	WIFI6 (802.11ax1)
HOT function	Bluetooth 5.2
Speaker	8Ω/1W*4
Touch	Support (10 finger)
Active Stylus	Support (MPP protocol)
I/O	1*512G M.2 2242 2* Type C 1*Micro HDMI
Battery capacity	38Wh(7.6V/5000mAh)
Dimension	317.38*214.34*10.2mm



https://changingtouch.com

If you need any help, please don't hesitate to contact us via the email address help@changingtouch.com and we will help you solve the problems as soon as possible.